





Poly Studio X50 Display Mounting Kit




Top of Display
 Haut de l'écran
 Display, unten
 Parte superior de la pantalla
 Parte superiore del display
 Parte superior da tela
 Góra ekranu
 Kijelző teteje
 Toppen av displayet
 ディスプレイの上部
 디스플레이 상단
 显示屏顶部
 顯示器頂部




2 VESA Mounting Options





3



4




5





Bottom of Display

Bas de l'écran
 Display, oben
 Parte inferior de la pantalla
 Parte inferiore del display
 Parte inferior da tela
 Dół ekranu
 Kijelző alja
 Bunnan av displayet
 ディスプレイの下部
 디스플레이 하단
 显示屏底部
 顯示器底部




2

VESA Mounting Options



3



4

